



RYB+(9.0V)

RB+(12V)
1
G
2
D12
3
CON3 HEADER 3
(TO PWR)

LED4 BLUE
LED2 GRN
LED3 ORG
LED6 WHT

R29 18K (2012)
R66 18K (2012)
R67 18K (2012)
R12 18K (2012)

C31 10uF / 6.3V

CD
1
AUX1
2
AUX2
3
RYB+ (9V)
4
NC
5
CHASSIS-GND
6
CON13-SELE
HEADER 4
(TO BACK)

AUX2
AUX1
CD
PHONO
-OFF
SELESW2
SW2

CON13 HEADER 3 (TO PWR)

SELECTOR SW

